



**FR**

- 1** Procéder à la découpe en croix de l'étanchéité.
- 2** Si présence isolant découper ce dernier.
- 3** Placer le solin sous la découpe de l'étanchéité.
- 4** Rabattre l'étanchéité sur la plaque et les coller entre eux (ou bien les souder selon les procédés).
- 5** Compléter l'étanchéité par une bande roulée sur la remontée de l'embase.
- 6** Placer le collier articulé et le manchon de raccordement fournis sur le chapeau Ventélia. Fixer le manchon de raccordement à l'aide d'une bande adhésive par exemple.
- 7** Emboîter l'ensemble dans le solin.
- 8** Procéder à la mise à niveau et serrer les vis six pans avec une clé Allen adaptée.

**EN**

- 1** Cut the roof membrane in a cross shape to allow it to be folded back for use later on. (do not completely cut membrane away, see step 4)
- 2** If necessary, remove the roof insulation as well.
- 3** Install the flat flashing and fix it when necessary.
- 4** Overlap the roof membrane over the flashing edges.
- 5** Add a piece of roof membrane around the flashing upstand to ensure water tightness.
- 6** Place the supplied Swivel Collar and Connecting Sleeve on the Ventelia cap. Attach the connection sleeve with adhesive tape, for example.
- 7** Fit the assembly into the flashing.
- 8** Check if Ventelia stack is level and adjust if necessary. Use an allen key to secure Ventelia to its ashing.